LED GLASS TUBE

Economic and Energy Efficiency

LITE ECO

Features

- ◆ Up to 50% energy saving compared with fluorescents
- ◆ Excellent light transmittance and uniform light
- ◆ High quality GLASS tube with eco-friendly coating
- ◆ Long lifetime up to 30,000hrs
- Easy installation
- ◆ No mercury material or UV radiation

Benefits

- ◆ Considerably lower energy cost
- ◆ Lowering maintenance cost
- Easy and flexible installation
- ◆ Environmental friendly


Application

• For general lighting in e.g. supermarkets, offices, hotels, residentials and restaurants



Approved by Suruhanjaya Tenaga (ST)

Dimension



Specification

* Dimming not allowed, not for use with electronic ballast gear.

Model	Dimension	Lampholder	Input Voltage	Power	Lumen	Efficiency	CCT(K)	CRI	Beam Angle	Power Factor
RLASELE721023	Ø26x588	G13	200-240V 50/60Hz	9W	900lm	100lm/W	3000K	80	300	>0.90
RLASELE721024	Ø26x588	G13	200-240V 50/60Hz	9W	900lm	100lm/W	4000K	80	300	>0.90
RLASELE721026	Ø26x588	G13	200-240V 50/60Hz	9W	900lm	100lm/W	6500K	80	300	>0.90
RLASELE741823	Ø26x1198	G13	200-240V 50/60Hz	18W	1800lm	100lm/W	3000K	80	300	>0.90
RLASELE741824	Ø26x1198	G13	200-240V 50/60Hz	18W	1800lm	100lm/W	4000K	80	300	>0.90
RLASELE741826	Ø26x1198	G13	200-240V 50/60Hz	18W	1800lm	100lm/W	6500K	80	300	>0.90

*SJ Lite reserves the right to change and amend the specification without prior notice.

Retrofit Lamp Installation instructions:
















LED Glass Tube Lamp Installation instructions:

- (1) Switch off the power supply.
- (2) Turning the conventional lamp 90°.
- (3) Remove the conventional lamp.
- (4) Remove the conventional starter from the starter holder.
- (5) Insert the LED starter into the starter holder.
- (6) Insert the LED glass lamp into the lamp holder.
- (7) Secure it in position by turning the lamp 90°.
- (8) Switch on the power supply. (200-240V $\sim 50/60$ Hz)

Installation instructions:

- (1) Switch off electricity.
- (2) and (3) Remove the conventional lamp and capacitor.
- (4) and (5) Retrofit refer to wiring method diagram b:
 - a) Bypass CCG & Replace the old starter with the LED tube starter.
- (6) Insert the LED lamp into the lamp holder.
- (7) Secure it in position by turning the lamp 90°.
- (8) Switch on electricity.







Do not use with





od for the new fixture (Complete Fixture)









This Lamp is suitable for 50Hz or 60Hz operation.

SIRIJAYA INDUSTRIES SDN. BHD. (Co. No. 153828-D)

No.9 Lebuh Perusahaan Klebang 9, IGB International Industrial Park, 31200 Chemor, Perak Darul Ridzuan, Malaysia. Tel: +605-292 3888 (Hunting Line), 291 2223 - 291 2228 Fax: +605-291 2221, 291 2222

Email: marketing@sirijaya.com Website: www.sirijaya.com

SJ LITE SINGAPORE PTE. LTD. (Co. No. 200609376-E)

5 Ubi Link #04- 00 Singapore 408548. Tel: +65-6844 3887

Fax: +65-6744 3886 Email: sjlite@singnet.com.sg